

SOUND LEVEL DATALOGGER

Features

- ▶ RS232 Interface
- ▶ 32,000 Records Datalogger
- ▶ Bargraph Indication
- ▶ MAX / MIN Function
- ▶ Auto Ranging (30~130dB)
- ▶ Resolution 0.1 dB
- ▶ Clock Display
- ▶ Level Range Display



If one needs long time on site sound monitoring, **C 322** will be the choice. With its built in 32000 records deep memory, it can gather all the data you need just by this tester .

Meter Display gives the decibel level, Bargraph display, with either fast or slow time weighting. After the data is collected, the user can download the data to the computer at his convenient place.

SPECIFICATIONS

Level Range	Lo = 30~80dB; Med = 50 ~ 100dB; Hi = 80~130dB
Accuracy	± 1.5dB (ref 94dB@ 1KHz)
Frequency Weighting	A / C
Time Weighting	Fast, Slow
Dynamic Range	50dB
Frequency Range	31.5Hz to 8KHz
Microphone	Electret condenser microphone
Auxiliary Outputs	AC / DC Output
Battery	9V battery
Dimensions	275 × 64 × 30 mm
Weight	Approx. 280g

Standard Accessories

Battery, Operation Manual, Carrying Case, Calibration Screwdriver, Windscreen, 3.5 φ plug, Software, RS 232 cable.