

# Digital Moisture Meter



Moisture measurements can be taken using the integral pin electrodes or using the heavy-duty moisture probe. Eight Calibration Scale makes the instrument usable for very wide range of wood species and any other hard materials. Automatically Temperature compensated when used with the temperature probe. Calibration Check Facility. Auto shut off mode to save the battery.

## Features :



- ▶ Large LCD Display
- ▶ Automatically Temperature Corrected (ATC) Reading when used with Temperature Probe
- ▶ Reading with Moisture Probe
- ▶ Readings with Integral Electrode Pins



Built in Pins



Auto Temp. Compensation



External Probe

**Model : EQ-129**

## SPECIFICATION :

Measuring Principle	Electrical Resistance
Electrode length	8mm Replaceable Type
Electrodes	Integrated, replaceable
Measuring Range	6 ~ 99%
Display Accuracy	± 1%
Battery	2 × AAA Batteries
Housing	Impact-proof plastic housing
Ambient Temperature	0 ~ 40°C
Ambient Moisture	0 ~ 85%
Size (H × W × D)	180mm × 50mm × 31mm
Weight	175g