

Hydromette Compact Moisture Meter

Microprocessor based Pocket type Moisture meter with LCD display and rugged housing so that the pins on the end of the instrument can be pressed into the material to be measured. One single instrument can be used to measure moisture content in almost any Hard material. However, the instrument is subject to be calibrated for that particular material or a Factor can be arrived at wherein the factor is multiplied to achieve the exact moisture content.

Application

- ▶ Wood Boards, Timber
- ▶ Card Boards, Papers
- ▶ Corrugated Box
- ▶ Dry Fruits
- ▶ Concrete

Specifications

Display	LCD
Measuring Range	0 to 90% m.c
Resolution	0.1% m.c
Accuracy	± 1%
Operating Voltage	Battery 9V
Dimension	L 140 x W 90 x H 50 mm
Weight	220gms



Equinox Hydromette

Optional : Calibrator to calibrate the instrument

Model : GM – CAL – 1

